



WET APPLICATION MINI COOPER BONNET STRIPES

What you need :

- Spray bottle with a mixture of water and dish soap
- A plastic squeegee
- A cutter

- 1** Prepare the water mixture, with 98% water and 2% dish soap
- 2** Clean and degrease the intended spot of placement thoroughly.
- 3** Put the stripes upside down on a flat surface, such as a table, or... the Mini roof.
- 4** Remove the silicon protective sheet, the adhesive side of the decal is facing you.
- 5** Spray the adhesive side, not excessively
- 6** Spray the bonnet, not excessively. The spray should look like a morning dew.
- 7** Place your decal in the desired position, and slide it to adjust the position.
- 8** Use your squeegee and apply pressure from the middle to the outward sides, this will remove all water and start the decal adhesion. This step is VERY important, so take your time.
- 9** Once all air bubbles have been removed, wait a few minutes to allow the decal to dry a little bit.
- 10** If the stripes are larger than the bonnet, cut the excess at the top and bottom of the bonnet with a cutter, following the bonnet edges.
- 11** Remove the transfer sheet
- 12** Prick any air bubbles with a pin and rub down
- 13** Enjoy your work !



WET APPLICATION MINI COOPER ROOF GRAPHIC

What you need :

- Spray bottle with a mixture of water and dish soap
- A plastic squeegee
- A cutter

- 1** Prepare the water mixture, with 98% water and 2% dish soap
- 2** Clean and degrease the intended spot of placement thoroughly.
- 3** Put the stripes upside down on a flat surface, such as a table, or... the Mini roof.
- 4** Remove the silicon protective sheet, the adhesive side of the decal is facing you.
- 5** Spray the adhesive side, not excessively
- 6** Spray the roof, not excessively. The spray should look like a morning dew.
- 7** Place your decal in the desired position, and slide it to adjust the position.
- 8** Use your squeegee and apply pressure from the middle to the outward sides, this will remove all water and start the decal adhesion. This step is VERY important, so take your time.
- 9** Once all air bubbles have been removed, wait a few minutes to allow the decal to dry a little bit.
- 10** Remove the transfer sheet
- 11** Prick any air bubbles with a pin and rub down
- 12** Repeat the same process with each graphic part.
- 13** Enjoy your work !



WET APPLICATION A-PANEL GRAPHICS

What you need :

- Spray bottle with a mixture of water and dish soap
- A plastic squeegee
- A cutter

- 1** Prepare the water mixture, with 98% water and 2% dish soap
- 2** Clean and degrease the intended spot of placement thoroughly.
- 3** Put the stripes upside down on a flat surface, such as a table, or... the Mini roof.
- 4** Remove the silicon protective sheet, the adhesive side of the decal is facing you.
- 5** Spray the adhesive side, not excessively
- 6** Spray the a-panel, not excessively. The spray should look like a morning dew.
- 7** Place your decal in the desired position, and slide it to adjust the position.
- 8** Use your squeegee and apply pressure from the middle to the outward sides, this will remove all water and start the decal adhesion. This step is VERY important, so take your time.
- 9** Once all air bubbles have been removed, wait a few minutes to allow the decal to dry a little bit.
- 10** Remove the transfer sheet, and prick any air bubbles with a pin and rub down
- 11** Repeat the same process with each graphic part.
- 12** Cut the excess that cover plastics. Cut also the graphic if it is between a door and the panel, wapping it inside the door.
- 13** Enjoy your work !